



1/10 [Name of Document] DRAWINGS START INITIALIZATION PITCH RANGE SETTING BUTTON OPERATED ? YES SOUND PITCH RANGE SETTING PROCESS:
DISPLAY PITCH RANGE SETTING SCREEN,
DETECT PITCH OF INPUT SOUND, INDICATE
CORRE. KEYBOARD REGION & SET FILTER
FOR PITCH EXTRACTION NO LEVEL SETTING BUTTON OPERATED ? YES SOUND VOLUME THRESHOLD VALUE
SETTING PROCESS:
DISPLAY LEVEL SETTING SCREEN, DETECT
LEVEL OF INPUT SOUND, INDICATE LEVEL
METER CORRE. TO DETECTED LEVEL & SET
THRESHOLD VALUE CORRE. TO MAXIMUM
LEVEL NO ROUNDING CONDITION DESIGNATING BUTTON OPERATED ? YES ROUNDING CONDITION
SETTING PROCESS:
MODIFY FILTER COEFFICIENT/
CONDITION TO MEET DESIGNATED
ROUNDING CONDITION NO PERFORMANCE/ MUSICAL NOTATION-RELATED BUTTON OPERATED ? YES SETTING OPERATION CORRE. TO DESIGNATION NO MUSICAL NOTATION & PERFORMANCE PROCESSES


1

F


IG.









F I G. 4







(A)

